

Table of Contents

Chapter 1: Getting Started

Introduction	1-2
The Purpose of this Manual	1-2
Where to Begin	1-2
Supplemental Manuals	1-2
Technical Support	1-2
Conventions Used	1-3
Key Topics for Each Chapter	1-3
DL205 System Components	1-4
CPUs	1-4
Bases	1-4
I/O Configuration	1-4
I/O Modules	1-4
Programming Methods	1-4
<i>Direct</i> SOFT32 Programming for Windows	1-4
Handheld Programmer	1-4
DL205 System Diagrams	1-5
DirectLOGIC Part Numbering System	1-7
Quick Start for PLC Validation and Programming	1-9
Step 1: Unpack the DL205 Equipment	1-9
Step 2: Install the CPU and I/O Modules	1-10
Step 3: Remove Terminal Strip Access Cover	1-10
Step 4: Add I/O Simulation	1-10
Step 5: Connect the Power Wiring	1-11
Step 6: Connect the Handheld Programmer	1-11
Steps to Designing a Successful System	1-12
Step 1: Review the Installation Guidelines	1-12
Step 2: Understand the CPU Setup Procedures	1-12
Step 3: Understand the I/O System Configurations	1-12
Step 4: Determine the I/O Module Specifications and Wiring Characteristics	1-12
Step 5: Understand the System Operation	1-12
Step 6: Review the Programming Concepts	1-13
Step 7: Choose the Instructions	1-13
Step 8: Understand the Maintenance and Troubleshooting Procedures	1-13

Chapter 2: Installation, Wiring, and Specifications

Safety Guidelines	2-2
Plan for Safety	2-2
Safety Techniques	2-2
Class 1, Division 2 Approval	2-2
Orderly System Shutdown	2-3
System Power Disconnect	2-3
Mounting Guidelines	2-4
Base Dimensions	2-4
Panel Mounting and Layout	2-5

Enclosures	2-6
Environmental Specifications	2-7
Power	2-7
Agency Approvals	2-7
Component Dimensions	2-8
Installing DL205 Bases	2-9
Choosing the Base Type	2-9
Mounting the Base	2-9
Using Mounting Rails	2-10
Installing Components in the Base	2-11
Base Wiring Guidelines	2-12
Base Wiring	2-12
I/O Wiring Strategies	2-13
PLC Isolation Boundaries	2-13
Powering I/O Circuits with the Auxiliary Supply	2-14
Powering I/O Circuits Using Separate Supplies	2-15
Sinking / Sourcing Concepts	2-16
I/O "Common" Terminal Concepts	2-17
Connecting DC I/O to "Solid State" Field Devices	2-18
Solid State Input Sensors	2-18
Solid State Output Loads	2-18
Relay Output Guidelines	2-20
Surge Suppression For Inductive Loads	2-20
Prolonging Relay Contact Life	2-22
I/O Modules Position, Wiring, and Specification	2-24
Slot Numbering	2-24
Module Placement Restrictions	2-24
Special Placement Considerations for Analog Modules	2-25
Discrete Input Module Status Indicators	2-25
Color Coding of I/O Modules	2-25
Wiring the Different Module Connectors	2-26
I/O Wiring Checklist	2-27
Glossary of Specification Terms	2-28
DL205 Modules	2-30
Chapter 3: CPU Specifications and Operations	
Overview	3-2
General CPU Features	3-2
DL230 CPU Features	3-2
DL240 CPU Features	3-2
DL250-1 CPU Features	3-3
DL260 CPU Features	3-3
CPU General Specifications	3-4
CPU Base Electrical Specifications	3-5
CPU Hardware Features	3-6
Mode Switch Functions	3-7
Status Indicators	3-7
Adjusting the Analog Potentiometers	3-8
Communication Ports	3-8
Port 1 Specifications	3-9

Port 2 Specifications	3-10
Using Battery Backup	3-11
Enabling the Battery Backup	3-11
Selecting the Program Storage Media	3-12
Built-in EEPROM	3-12
EEPROM Sizes	3-12
EEPROM Operations	3-12
CPU Setup	3-13
Installing the CPU	3-13
Connecting the Programming Devices	3-13
Auxiliary Functions	3-14
Clearing an Existing Program	3-15
Setting the Clock and Calendar	3-15
Initializing System Memory	3-15
Setting the CPU Network Address	3-16
Setting Retentive Memory Ranges	3-16
Password Protection	3-16
Setting the Analog Potentiometer Ranges	3-17
CPU Operation	3-19
CPU Operating System	3-19
Program Mode Operation	3-20
Run Mode Operation	3-20
Read Inputs	3-21
Read Inputs from Specialty and Remote I/O	3-21
Service Peripherals and Force I/O	3-21
CPU Bus Communication	3-22
Update Clock, Special Relays, and Special Registers	3-22
Solve Application Program	3-23
Solve PID Loop Equations	3-23
Write Outputs	3-23
Write Outputs to Specialty and Remote I/O	3-24
Diagnostics	3-24
I/O Response Time	3-25
Is Timing Important for Your Application?	3-25
Normal Minimum I/O Response	3-25
Normal Maximum I/O Response	3-25
Improving Response Time	3-26
CPU Scan Time Considerations	3-27
Initialization Process	3-28
Reading Inputs	3-28
Reading Inputs from Specialty I/O	3-29
Service Peripherals	3-29
CPU Bus Communication	3-30
Update Clock / Calendar, Special Relays, Special Registers	3-30
Writing Outputs	3-30
Writing Outputs to Specialty I/O	3-31
Diagnostics	3-31
Application Program Execution	3-32
PLC Numbering Systems	3-33
PLC Resources	3-33
V-Memory	3-34

Binary-Coded Decimal Numbers	3-34
Hexadecimal Numbers	3-34
Memory Map	3-35
Octal Numbering System	3-35
Discrete and Word Locations	3-35
V-Memory Locations for Discrete Memory Areas	3-35
Input Points (X Data Type)	3-36
Output Points (Y Data Type)	3-36
Control Relays (C Data Type)	3-36
Timers and Timer Status Bits (T Data type)	3-36
Timer Current Values (V Data Type)	3-37
Counters and Counter Status Bits (CT Data type)	3-37
Counter Current Values (V Data Type)	3-37
Word Memory (V Data Type)	3-37
Stages (S Data type)	3-38
Special Relays (SP Data Type)	3-38
Remote I/O Points (GX Data Type)	3-38
DL230 System V-memory	3-39
DL240 System V-memory	3-41
DL250-1 System V-memory (applies to DL250)	3-44
DL260 System V-memory	3-47
DL230 Memory Map	3-50
DL240 Memory Map	3-51
DL250-1 Memory Map	3-52
DL260 Memory Map	3-53
X Input / Y Output Bit Map	3-54
Control Relay Bit Map	3-56
Staget Control / Status Bit Map	3-60
Timer and Counter Status Bit Maps	3-62
Remote I/O Bit Map (DL 260 only)	3-63
Chapter 4: System Design and Configuration	
DL205 System Design Strategies	4-2
I/O System Configurations	4-2
Networking Configurations	4-2
Module Placement	4-3
Slot Numbering	4-3
Module Placement Restrictions	4-3
Automatic I/O Configuration	4-4
Manual I/O Configuration	4-4
Removing a Manual Configuration	4-5
Power-On I/O Configuration Check	4-5
I/O Points Required for Each Module	4-6
Calculating the Power Budget	4-7
Managing your Power Resource	4-7
CPU Power Specifications	4-7
Module Power Requirements	4-7
Power Budget Calculation Example	4-9
Power Budget Calculation Worksheet	4-10
Local Expansion I/O	4-11

D2–CM Local Expansion Module	4–11
D2–EM Local Expansion Module	4–12
D2–EXCBL–1 Local Expansion Cable	4–12
DL260 Local Expansion System	4–13
DL250–1 Local Expansion System	4–14
Expansion Base Output Hold Option	4–15
Enabling I/O Configuration Check using DirectSOFT32	4–16
Remote I/O Expansion	4–17
How to Add Remote I/O Channels	4–17
Configuring the CPU's Remote I/O Channel	4–18
Configure Remote I/O Slaves	4–20
Configuring the Remote I/O Table	4–20
Remote I/O Setup Program	4–21
Remote I/O Test Program	4–22
Network Connections to MODBUS and DirectNet	4–23
Configuring Port 2 For DirectNet For MODBUS RTU	4–23
MODBUS Port Configuration	4–24
DirectNET Port Configuration	4–25
Network Slave Operation	4–26
MODBUS Function Codes Supported	4–26
Determining the MODBUS Address	4–26
If Your Host Software Requires the Data Type and Address...	4–26
Example 1: V2100	4–28
Example 2: Y20	4–28
Example 3: T10 Current Value	4–28
Example 4: C54	4–28
If the Host Software Requires an Address ONLY	4–29
Example 1: V2100 584/984 Mode	4–31
Example 2: Y20 584/984 Mode	4–31
Example 3: T10 Current Value 484 Mode	4–31
Example 4: C54 584/984 Mode	4–31
Network Master Operation	4–32
Step 1: Identify Master Port # and Slave #	4–33
Step 2: Load Number of Bytes to Transfer	4–33
Step 3: Specify Master Memory Area	4–34
Step 4: Specify Slave Memory Area	4–34
Communications from a Ladder Program	4–35
Multiple Read and Write Interlocks	4–35
Network MODBUS RTU Master Operation (DL260 only)	4–36
MODBUS Function Codes Supported	4–36
MODBUS Port Configuration	4–37
RS–485	4–38
Network	4–38
RS–232	4–38
Network	4–38
MODBUS Read from Network (MRX)	4–39
MRX Slave Memory Address	4–40
MRX Master Memory Addresses	4–40
MRX Number of Elements	4–40
MRX Exception Response Buffer	4–40
MODBUS Write to Network (MWX)	4–41

MWX Slave Memory Address	4-42
MWX Master Memory Addresses	4-42
MWX Number of Elements	4-42
MWX Exception Response Buffer	4-42
MRX / MWX Example in DirectSOFT32	4-43
Multiple Read and Write Interlocks	4-43
DL260 Non-Sequence Protocol (ASCII In/Out and PRINT)	4-45
MODBUS Port Configuration	4-45
RS-485	4-46
Network	4-46
RS-232	4-46
Network	4-46
DL250-1 Non-Sequence Protocol (PRINT)	4-47
MODBUS Port Configuration	4-47
RS-422	4-48
Network	4-48
RS-232	4-48
Network	4-48
 Chapter 5: Standard RLL Instructions	
Introduction	5-2
Using Boolean Instructions	5-5
END Statement	5-5
Simple Rungs	5-5
Normally Closed Contact	5-5
Contacts in Series	5-6
Midline Outputs	5-6
Parallel Elements	5-6
Joining Series Branches in Parallel	5-7
Joining Parallel Branches in Series	5-7
Combination Networks	5-7
Boolean Stack	5-7
Comparative Boolean	5-8
Immediate Boolean	5-9
Boolean Instructions	5-10
Store (STR)	5-10
Store Not (STRN)	5-10
Store Bit-of-Word (STRB)	5-11
Store Not Bit-of-Word(STRNB)	5-11
Or (OR)	5-12
Or Not (ORN)	5-12
Or Bit-of-Word (ORB)	5-13
Or Not Bit-of-Word (ORNB)	5-13
And (AND)	5-14
And Not (ANDN)	5-14
And Bit-of-Word (ANDB)	5-15
And Not Bit-of-Word (ANDNB)	5-15
And Store (AND STR)	5-16
Or Store (OR STR)	5-16
Out (OUT)	5-17
Out Bit-of-Word (OUTB)	5-18

Or Out (OR OUT)	5-19
Not (NOT)	5-19
Positive Differential (PD)	5-20
Store Positive Differential (STRPD)	5-21
Store Negative Differential (STRND)	5-21
Or Positive Differential (ORPD)	5-22
Or Negative Differential (ORND)	5-22
And Positive Differential (ANDPD)	5-23
And Negative Differential (ANDND)	5-23
Set (SET)	5-24
Reset (RST)	5-24
Set Bit-of-Word (SETB)	5-25
Reset Bit-of-Word (RSTB)	5-25
Pause (PAUSE)	5-26
Comparative Boolean	5-27
Store If Equal (STRE)	5-27
Store If Not Equal (STRNE)	5-27
Or If Equal (ORE)	5-28
Or If Not Equal (ORNE)	5-28
And If Equal (ANDE)	5-29
And If Not Equal (ANDNE)	5-29
Store (STR)	5-30
Store Not (STRN)	5-30
Or (OR)	5-31
Or Not (ORN)	5-31
And (AND)	5-32
And Not (ANDN)	5-32
Immediate Instructions	5-33
Store Immediate (STRI)	5-33
Store Not Immediate (STRNI)	5-33
Or Immediate (ORI)	5-34
Or Not Immediate (ORNI)	5-34
And Immediate (ANDI)	5-35
And Not Immediate (ANDNI)	5-35
Out Immediate (OUTI)	5-36
Or Out Immediate (OROUTI)	5-36
Out Immediate Formatted (OUTIF)	5-37
Set Immediate (SETI)	5-38
Reset Immediate (RSTI)	5-38
Load Immediate (LDI)	5-39
Load Immediate Formatted (LDIF)	5-40
Timer, Counter and Shift Register Instructions	5-41
Using Timers	5-41
Timer (TMR) and Timer Fast (TMRF)	5-42
Timer Example Using Discrete Status Bits	5-43
Timer Example Using Comparative Contacts	5-43
Accumulating Timer (TMRA) Accumulating Fast Timer (TMRAF)	5-44
Accumulating Timer Example using Discrete Status Bits	5-45
Accumulator Timer Example Using Comparative Contacts	5-45
Counter (CNT)	5-46
Counter Example Using Discrete Status Bits	5-47

Counter Example Using Comparative Contacts	5-47
Stage Counter (SGCNT)	5-48
Stage Counter Example Using Discrete Status Bits	5-49
Stage Counter Example Using Comparative Contacts	5-49
Up Down Counter (UDC)	5-50
Up / Down Counter Example Using Discrete Status Bits	5-51
Up / Down Counter Example Using Comparative Contacts	5-51
Shift Register (SR)	5-52
Accumulator / Stack Load and Output Data Instructions	5-53
Using the Accumulator	5-53
Copying Data to the Accumulator	5-53
Changing the Accumulator Data	5-54
Using the Accumulator Stack	5-55
Using Pointers	5-57
Load (LD)	5-58
Load Double (LDD)	5-59
Load Formatted (LDF)	5-60
Load Accumulator Indexed from Data Constants (LDSX)	5-63
Load Real Number (LDR)	5-64
Out (OUT)	5-65
Out Double (OUTD)	5-66
OutFormatted (OUTF)	5-67
Out Indexed (OUTX)	5-68
Out Least (OUTL)	5-69
Out Most (OUTM)	5-69
Pop (POP)	5-70
Accumulator Logical Instructions	5-71
And (AND)	5-71
And Double (ANDD)	5-72
And Formatted (ANDF)	5-73
And with Stack (ANDS)	5-74
Or (OR)	5-75
Or Double (ORD)	5-76
Or Formatted (ORF)	5-77
Or with Stack (ORS)	5-78
Exclusive Or (XOR)	5-79
Exclusive Or Formatted (XORF)	5-81
Exclusive Or with Stack (XORS)	5-82
Compare (CMP)	5-83
Compare Double (CMPD)	5-84
Compare Formatted (CMPF)	5-85
Compare with Stack (CMPS)	5-86
Compare Real Number (CMPR)	5-87
Math Instructions	5-88
Add (ADD)	5-88
Add Double (ADDD)	5-89
Add Real (ADDR)	5-90
Subtract (SUB)	5-91
Subtract Double (SUBD)	5-92
Subtract Real (SUBR)	5-93
Multiply (MUL)	5-94

Multiply Double (MULD)	5-95
Multiply Real (MULR)	5-96
Divide (DIV)	5-97
Divide Double (DIVD)	5-98
Divide Real (DIVR)	5-99
Increment (INC)	5-100
Decrement (DEC)	5-100
Add Binary (ADDB)	5-101
Add Binary Double (ADDBD)	5-102
Subtract Binary (SUBB)	5-103
Subtract Binary Double (SUBBD)	5-104
Multiply Binary (MULB)	5-105
Divide Binary (DIVB)	5-106
Increment Binary (INCB)	5-107
Decrement Binary (DECB)	5-108
Add Formatted (ADDF)	5-109
Subtract Formatted (SUBF)	5-110
Multiply Formatted (MULF)	5-111
Divide Formatted (DIVF)	5-112
Add Top of Stack (ADDS)	5-113
Subtract Top of Stack (SUBS)	5-114
Multiply Top of Stack (MULS)	5-115
Divide by Top of Stack (DIVS)	5-116
Add Binary Top of Stack (ADDBS)	5-117
Subtract Binary Top of Stack (SUBBS)	5-118
Multiply Binary Top of Stack (MULBS)	5-119
Divide Binary by Top OF Stack (DIVBS)	5-120
Transcendental Functions	5-121
Sine Real (SINR)	5-121
Cosine Real (COSR)	5-121
Tangent Real (TANR)	5-121
Arc Sine Real (ASINR)	5-121
Arc Cosine Real (ACOSR)	5-122
Arc Tangent Real (ATANR)	5-122
Square Root Real (SQRTR)	5-122
Bit Operation Instructions	5-123
Sum (SUM)	5-123
Shift Left (SHFL)	5-124
Shift Right (SHFR)	5-125
Rotate Left (ROTL)	5-126
Rotate Right (ROTR)	5-127
Encode (ENCO)	5-128
Decode (DECO)	5-129
Number Conversion Instructions (Accumulator)	5-130
Binary (BIN)	5-130
Binary Coded Decimal (BCD)	5-131
Invert (INV)	5-132
Ten's Complement (BCDCPL)	5-133
Binary to Real Conversion (BTOR)	5-134
Real to Binary Conversion (RTOB)	5-135
Radian Real Conversion (RADR)	5-136

Degree Real Conversion (DEGR)	5-136
ASCII to HEX (ATH)	5-137
HEX to ASCII (HTA)	5-138
Segment (SEG)	5-140
Gray Code (GRAY)	5-141
Shuffle Digits (SFLDGT)	5-142
Shuffle Digits Block Diagram	5-142
Table Instructions	5-144
Move (MOV)	5-144
Move Memory Cartridge / Load Label (MOVMC) (LDLBLE)	5-145
Copy Data From a Data Label Area to V Memory	5-146
Copy Data From V Memory to a Data Label Area	5-147
Set Bit (SETBIT)	5-148
Reset Bit (RSTBIT)	5-148
Fill (FILL)	5-150
Find (FIND)	5-151
Find Greater Than (FDGT)	5-152
Table to Destination (TTD)	5-154
Remove from Bottom (RFB)	5-157
Source to Table (STT)	5-160
Remove from Table (RFT)	5-163
Add to Top (ATT)	5-166
Table Shift Left (TSHFL)	5-169
Table Shift Right (TSHFR)	5-169
AND Move (ANDMOV)	5-171
OR Move (ORMOV)	5-171
Exclusive OR Move (XORMOV)	5-171
Find Block (FINDB)	5-173
Swap (SWAP)	5-174
Clock / Calendar Instructions	5-175
Date (DATE)	5-175
Time (TIME)	5-176
CPU Control Instructions	5-177
No Operation (NOP)	5-177
End (END)	5-177
Stop (STOP)	5-178
Reset Watch Dog Timer (RSTWT)	5-178
Program Control Instructions	5-179
Goto Label (GOTO) (LBL)	5-179
For / Next (FOR) (NEXT)	5-180
Goto Subroutine (GTS) (SBR)	5-182
Subroutine Return (RT)	5-182
Subroutine Return Conditional (RTC)	5-182
Master Line Set (MLS)	5-185
Master Line Reset (MLR)	5-185
Understanding Master Control Relays	5-185
MLS/MLR Example	5-186
Interrupt Instructions	5-187
Interrupt (INT)	5-187
Interrupt Return (IRT)	5-188
Interrupt Return Conditional (IRTC)	5-188

Enable Interrupts (ENI)	5-188
Disable Interrupts (DISI)	5-188
Interrupt Example for Interrupt Module	5-189
Interrupt Example for Software Interrupt	5-190
Intelligent I/O Instructions	5-191
Read from Intelligent Module (RD)	5-191
Write to Intelligent Module (WT)	5-192
Network Instructions	5-193
Read from Network (RX)	5-193
Write to Network (WX)	5-195
Message Instructions	5-197
Fault (FAULT)	5-197
Fault Example	5-198
Data Label (DLBL)	5-199
ASCII Constant (ACON)	5-199
Numerical Constant (NCON)	5-199
Data Label Example	5-200
Print Message (PRINT)	5-201
MODBUS RTU Instructions (DL260)	5-205
MODBUS Read from Network (MRX)	5-205
MRX Slave Memory Address	5-206
MRX Master Memory Addresses	5-206
MRX Number of Elements	5-206
MRX Exception Response Buffer	5-206
MRX Example	5-207
MODBUS Write to Network (MWX)	5-208
MWX Slave Memory Address	5-209
MWX Master Memory Addresses	5-209
MWX Number of Elements	5-209
MWX Exception Response Buffer	5-209
MWXExample	5-210
ASCII Instructions (DL260)	5-211
Reading ASCII Input Strings	5-211
Writing ASCII Output Strings	5-211
Managing the ASCII Strings	5-211
ASCII Input(AIN)	5-212
ASCII Find (AFIND)	5-216
AFIND Search Example	5-217
ASCII Extract (AEX)	5-219
ASCII Compare (CMPV)	5-220
ASCII Print to V-memory (VPRINT)	5-221
ASCII Print from V-memory (PRINTV)	5-226
ASCII Swap Bytes (SWAPB)	5-227
Byte Swap Preferences	5-227
ASCII Clear Buffer (ACRB)	5-228