

Table of Contents

Chapter 1: Getting Started

Introduction	1-2
The Purpose of this Manual	1-2
Supplemental Manuals	1-2
Who Should Read this Manual	1-2
Technical Support	1-2
Conventions Used	1-3
Key Topics for Each Chapter	1-3
Introduction to DeviceNet	1-4
DeviceNet Concepts	1-4
The ODVA	1-4
General Information about the D0-DEVNETS	1-5
Specifications	1-5
Mini Glossary	1-5

Chapter 2: Installing the DeviceNet Slave Module

Installing the D0-DEVNETS Slave Module	2-2
Setting the DIP Switch (SW1)	2-2
Remove the Slot Cover	2-4
Insert the Module	2-5
Set the Node Address	2-6
Wiring the Adapter to a DeviceNet Network	2-6
Configure the Adapter	2-7
Configuring the DeviceNet Adapter	2-7
Status Indicators	2-8
D0-DEVNETS Parameter Setup	2-9
D0-DEVNETS Default Parameters	2-9
Software and Firmware Requirements	2-10
How to Update Your DirectSOFT32 Programming Software	2-10
How to Update Your DL05 Firmware	2-11
Changing the D0-DEVNETS Setup Parameters	2-12

Appendix A: Specifications

Appendix B: Tables

Data Input and Output Tables	B-2
Device Profile Tables	B-5

Appendix C: Image Table Mapping

Image Table Mapping	C-2
PLC Mode Image Table Mapping	C-8

Appendix D: Special Relays and DIP Switch Parameter Initializing

Network Status Special Relays	D-2
Initializing Parameter Values	D-2

Appendix E: D0-DEVNETS Think & Do/Entivity Setup

D0-DEVNETS Think & Do/Entivity Setup	E-2
T&D/Entivity setup for PC control	E-2
Setup Think & Do with DL05 on a network	E-4
T & D Studio setup	E-5

Appendix F: OIT with D0-DEVNETS

Using an OIT with D0-DEVNETS	F-2
T&D Studio	F-2

Appendix G: D0-DEVNETS and Allen-Bradley Set up

Setup D0-DEVNETS with Allen-Bradley RSNetWorxt	G-2
RSLinx	G-2
RSLogix	G-6
Configure D0-DEVNETS with RSNetWorx	G-8
Using the EDS file	G-8
Go on line	G-11
Set up I/O parameters	G-12
Map the nodes	G-15
Set Class Instance Attribute	G-18